

SPARE PARTS LIST FOR FURUKAWA

PART NUMBER	PART NAME	CATALOGUE FIG	MACHINERY
03409-16002	PISTON ROD	8-10/2	FL170A
111311-06032	PIN SPRING	3-17/012	FL170A
352351-32170	CARRIER PLANETARY	3-17/006	FL170A
352351-32220	GEAR PLANETARY	3-17/010	FL170A
352351-32230	SHAFT PLAN.GEAR	3-17/011	FL170A
352351-32380	GEAR SUN	3-17/027	FL170A
352351-32310	PLATE	3-17/019	FL170A
352351-32280	GEAR INTERNAL	3-17/015	FL170A
93519-01012	PROPELLER SHAFT ASS'Y	3-1/4-6	FL120A
05004-01037	STEERING PIN	11-3/60.	FL220
05008-03001	CENTER PIN	8-1/11.	FL220
05008-03005	CENTER BUSHING	8-1/20.	FL220
05008-03007	CASTLE NUT	8-1/21.	FL220
05019-01003	FLANGE YOKE	4-3/1.	FL220
05122-01107	SEAL	7-11/6.	FL220
05122-01108	BOOT	7-11/7.	FL220
03504-01029	PIN STEERING	8-5/28	FL230
03504-12019	BEARING	8-15/20	FL230
03504-12025	BEARING	8-15/26	FL230
03504-12027	NUT	8-15/28	FL 230
03504-12028	RAIL RING	8-15/29	FL230
03504-12042	SECTOR SHAFT	8-15/36	FL 230
05003-01017	BACK PLATE	3-9/8	FL230
05003-01026	REAMER BOLT	3-9/27	FL230
05003-01043	RING SQUARE	3-13/15.	FL 230
05004-01037	PIN STEERING	8-5/1	FL 230
05008-04006	BUSHING	9-3/3	FL 230
05009-01013	PIN	12-5/16	FL 230
05009-01016	PIN	12-5/18	FL 230
05009-01017	PIN	12-5/17	FL 230
05009-01018	PIN	12-5/21	FL 230
05009-01019	PIN	12-5/31	FL 230
05009-01024	BUSHING	12-5/34	FL 230
05009-01032	TOOTH	12-5/8	FL 230
05009-01038	PIN	12-5/19	FL 230
05009-03025	PIN	12-13/18	FL 230
05009-03026	PIN	12-13/17	FL 230
05009-04025	BUSHING	12-15/19	FL230
05018-02093	STATOR HUB	2-3/6	FL230
05018-02094	STATOR WHELL	2-3/8	FL 230
05020-03024	PLANETARY GEAR	5-5/29	FL 230
05020-03026	PLANETARY GEAR SHAFT	5-5/31	FL 230
05020-03027	THRUST RING	5-5/32.	FL230
05020-03032	PLANETARY GEAR CASE	5-5/26	FL230
05104-03018	U-NUT	8-9/17.	FL230
05109-01006	PIN	12-5/20	FL 230
05109-01020	BUSHING	12-5/30	FL 230

05109-01046	PIN	12-5/23	FL 230
05109-01047	PIN	12-5/22	FL 230
05119-04014	SEE 95219-02017		FL 230
05119-04018	SEE 95219-02017		FL 230
05120-01024	NUT	5-1/25.	FL230
05120-03061	AXLE TUBE	5-5/2	FL 230
05120-03066	SUN GEAR	5-5/47	FL 230
05120-03070	LOCK NUT	5-5/40	FL 230
05120-03083	INTERNAL GEAR FLANGE	5-5/18	FL 230
05120-03088	SEAL	5-5/12.	FL230
05120-03092	INTERNAL GEAR	5-5/19	FL 230
05120-03098	RETAINER	5-5/54	FL230
05122-14006	LINING PAD	6-5/4	FL230
05122-14012	PISTON BRAKE	6-6-1/10	FL 230
05122-14015	RUBBER PARTS KIT	6-5/9-11-12	FL 230
05201-06018	PRE-CLEANER		FL230
05220-04105	DISC BRAKE	5-5/55	FL 230
05303-05002	GEAR B	3-9/22	FL230
05303-05003	CLUTCH CARRIER	3-9/21	FL 230
05303-05004	OIL SEAL RING	3-9/17	FL230
05303-05009	CLUTCH PISTON	3-13/16-3-9/16	FL 230
05303-05016	CLUTCH SHAFT	3-9/18	FL 230
05303-05020	GEAR C	3-9/5	FL230
05303-05025	GEAR A	3-9/31	FL230
05303-05028	OIL SEAL RING	3-9/20	FL230
05303-05029	CLUTCH CARRIER	3-9/23	FL 230
05303-07018	GEAR	3-13/5	FL230
05303-07019	GEAR F	3-13/19	FL230
05303-07022	GEAR D	3-13/21	FL230
05303-07025	BUSHING	3-13/6	FL 230
05303-11008	INPUT SHAFT	3-6/4	FL230
05303-11029	FLANGE	3-7/5	FL 230
05303-11069	DRIVE GEAR	3-5/2	FL230
05303-11086	STRAINER	3-1/2	FL 230
05303-11087	GEAR I	3-7/8	FL230
05304-03020	BUSHING	8-9/19	FL 230
05308-03008	COLLAR	9-1/24	FL 230
05308-03013	PIN	9-1/18	FL 230
05308-04002	PIN	9-3/2	FL 230
05309-01013	BUSHING	12-5/24	FL 230
05309-01014	BUSHING	12-5/25	FL 230
05309-01015	SPACER	12-5/26	FL 230
05309-01027	BUSHING	12-5/38	FL 230
05309-01042	BUSHING	12-5/38-1	FL 230
05309-02040	CABLE ASSY	12-9/34	FL230
05309-02047	CABLE ASSY	12-9/34-1	FL230
05309-03015	U NUT ROD LIFT	12-14/15	FL230
05309-04015	CASTLE NUT ROD TILT	12-16/15	FL230
05309-07039	OIL PIPE	12-2/9	FL230
05318-05012	FLANGE	3-5/5	FL 230
05318-05020	PUMP DRIVE SHAFT	2-7/15	FL230

05318-05028	TURBINE SHAFT	2-7/16	FL 230
05318-05031	PUMP DRIVE SHAFT	2-7+C35/23	FL230
05318-06004	IMPELLER WHELL	2-3/1	FL 230
05318-06007	STATOR HOLDER	2-3/4	FL 230
05318-06012	TURBINE WHELL	2-3/9	FL 230
05318-08002	OIL SEAL RING	2-3/18	FL230
05318-08003	CLUTCH PISTON	2-3/13	FL 230
05318-08004	OIL SEAL RING	2-3-14	FL230
05318-08005	SEAL CARRIER	2-3/15	FL 230
05318-08008	SEAL RACE	2-3/17	FL 230
05318-08009	OIL SEAL RING	2-3/18	FL 230
05318-08011	BACK PLATE	2-3/20	FL 230
05318-08015	BUSHING	2-3/23	FL230
05318-08020	COVER WHELL	2-3/28	FL 230
05320-01061	FLANGE	5-1/36	FL 230
05321-01004	BRAKE FLANGE	7-1/26	FL 230
05321-01028	FLANGE	7-1/4	FL 230
05322-12005	PIN ASS'Y	6-6-1/3	FL 230
05503-01054	OIL SEAL RING	*	FL 230
05508-03010	SHIM	9-1/22	FL 230
05508-03011	BUSHING	9-1/23	FL 230
05508-03019	SPACER	9-1/29	FL 230
05508-03020	SHIM	9-1/15	FL 230
05508-03021	SHIM	9-1/16	FL 230
05518-02018	OUTPUT FLANGE		FL230
05518-02080	HUB SPLINE		FL230
05521-01012	SPLINE SHAFT	7-1/14	FL 230
15204-801006	DUST SEAL	9-1/20	FL230
341031-11210	MUFFLER TAIL		FL230
341411-21002	DISC BRAKE ASS'Y R.H	6-6-1	FL 230
341411-22002	DISC BRAKE ASS'Y	6-6-1	FL 230
93504-12009	BALL NUT ASS'Y	8-15/7	FL 230
93504-12018	SLEEVE ASS'Y	8-15/19	FL 230
93504-12021	SPOOL ASS'Y	8-15/22	FL 230
95104-03001	CYLINDER STEERING TUBE	8-9/1	FL 230
95104-03002	PISTON ROD STEERING	8-9/2	FL 230
95122-14001	DISC BRAKE R.H	6-5	FL 230
95122-14002	DISC BRAKE	6-5	FL 230
95219-02017	PROPELLER SHAFT ASS'Y	4-1/2-3-W/O SPIDERS	FL 230
95303-11095	COVER ASS'Y	3-1/43	FL 230
95304-03023	STEERING CYLINDER ASS'Y	8-9	FL 230
95309-03002	LIFT CYLINDER PISTON ROD	12-13/2	FL 230
95318-08029	CLUTCH CARRIER ASSY	2-3/30	FL230
95319-01001	PROPELLER SHAFT ASS'Y	4-3. W/O SPIDERS	FL230
95319-01002	PROPELLER SHAFT ASS'Y	4-3. W/O SPIDERS	FL230
95319-01014	SEE 95319-01001		FL230
95319-01015	SEE 95319-01001		FL230
95319-01015	SEE 95319-01002		FL230
95319-01016	SEE 95319-01002		FL230
95322-12001	DISC BRAKE ASS'Y R.H	6-6/1	FL230
95322-12002	DISC BRAKE ASS'Y L.H	6-6/1	FL230

100212-14050	BOLT	9-1/13	FL230
100212-20080	BOLT	12-5/9.	FL230
100212-30060	BOLT	9-1/26	FL230
101321-12016	SCREW SET	5-5/41	FL230
103412-20160	NUT	12-5/10	FL230
108002-20051	WASHER SPRING	1-14	FL230
108202-20030	WASHER SPRING	1-14	FL230
341231-21290	BACK PLATE	2321-01/011	FL230-I
341221-11450	HUB SPLINE	2211-01/040	FL230-I
341221-11510	SHAFT DRIVE	2211-01/047	FL230-I
341221-11520	SHAFT DRIVE	2211-01/054	FL230-I
341221-12130	HOLDER-STATOR	2212-01/003	FL230-I
341231-23172	GEAR	2323-01/ 015	FL 230-1
341342-11000	PROPELLER SHAFT	3401-01/ 001	FL 230-1
341342-12000	PROPELLER SHAFT	3401-01/ 004	FL 230-1
341342-13000	PROPELLER SHAFT	3401-01/ 16-10	FL 230-1
341411-21221	PIN ASS'Y		FL 230-I
341811-21140	TOOTH	8111-01/ 602	FL 230-1
345351-12130	FLANGE GEAR	3511-01/ 110	FL 230-1
345351-12140	GEAR INTERNAL	3511-02/ 111	FL 230-1
345351-12160	NUT LOCK	3511-01/113	FL 230-1
345351-12210	GEAR SUN	3511-02/ 119	FL 230-1
345351-12241	CASE,GEAR	3511-01/121	FL 230-1
345351-12260	GEAR PLANETARY	3511-02/ 122	FL 230-1
345351-12280	WASHER THRUST	3511-02/ 124	FL 230-1
345351-12290	SHAFT	3511-02/ 125	FL 230-1
346351-12130	DISC	3511-01/ 205	FL 230-1
346411-21000	DISC BRAKE ASS'Y	4121-01	FL 230-1
346411-22000	DISC BRAKE ASS'Y	4121-01	FL230-I
05503-01052	OIL SEAL RING		FL 320 A
05503-01053	OIL SEAL RING		FL 320 A
05503-01115	OIL SEAL RING		FL 320 A
05503-01054	OIL SEAL RING		FL 320 A
341231-11280	COVER SUPPLY	3-1/13	FL 320 A
343411-21110	BODY A	7-1/21.	FL 320 A
343221-12120	HOLDER-STATOR	2-9/34.	FL 320 A
343221-12150	CARRIER SEAL	2-9/6	FL 320 A
343351-12190	FLANGE INTER GEAR	5-7/54	FL 320 A
343351-12210	GEAR INTERNAL	5-7/29	FL 320 A
345351-12310	GEAR SUN	5-7/24	FL 320 A
343351-12330	SHAFT PLANETARY	5-7/27	FL 320 A
343351-12350	GEAR PLANETARY	5-7/25	FL 320 A
343351-21590	FLANGE	5-3/27	FL 320 A
343351-21610	COVER	5-3/28	FL 320 A
343411-21120	BRAKE PISTON	7-1/10	FL 320 A
341351-12210	BOLT HUB	3-13/136	FL330-I
341351-12220	NUT HUB	3-13/137	FL330-I
341611-14110	SEAL DUST	6-10/002	FL330-I
343351-12190	FLANGE GEAR	3-13/107	FL330-I
343351-12210	GEAR	3-13/108	FL330-I
343351-12310	GEAR SUN	3-13/119	FL330-I

343351-12330	SHAFT	3-13/125	FL330-I
343351-12340	BEARING NEEDLE	5-7/26.	FL330-I
343351-12350	GEAR	3-13/122	FL330-I
343511-22340	SHAFT STEERING	5-8.	FL330-I
343811-11160	BUSHING	8-1/206	FL330-I
343811-11170	SPACER	8-1/205	FL330-I
343811-11490	PIN	8-1/150	FL330-I
344211-12140	TURBINE ASS'Y	2-9/006	FL330-I
344211-12230	REACTOR ASS'Y	2-9/010	FL330-I
344211-12360	REACTOR ASS'Y	2-9/017	FL330-I
344211-12460	PUMP	2-9/023	FL330-I
344211-13380	GRUOND SHAFT ASSY	2-13/29	FL330-I
344211-21340	GEAR,SUN	2-17/019	FL330-I
	PINION 19 TEETH	2121-01/101	FL330-I
	PIN	2121-01/106	FL330-I
	PINION 18 TEETH	2121-03/204	FL330-I
	PIN	2121-03/207	FL330-I

